
aspen aerogels



Predictive Performance: Visualizing a Lifetime of Mechanical Loads Within a Battery Module


Tyler Gurian, Senior Program Engineer

Aspen is The Global Leader in Aerogel Technology






Cell-to-Cell (C2C) Barriers Have Two Jobs




1. Mechanical Compression pad




Cell-to-Cell (C2C) Barriers Have Two Jobs

- PyroThin has achieved TP stop in applications as thin as 1.4mm
- PyroThin can be formulated to withstand extended exposure up to 1000°C
- PyroThin fully retains thermal and dielectric performance through End of Life
 - High strain, extended mechanical cycling, extreme climatic cycling, etc.




Cell-to-Cell (C2C) Barriers Have Two Jobs




Mechanical

Compression pad




aerogels


- Linear springs can be described with a technical specification
 - Spring constant = k




- Linear springs can be described with a *technical* specification
 - Spring constant = k
- Nonlinear springs are better described with *functional* specifications of the desired system-level behaviors
 - Minimum & maximum cell-face pressures





- Linear springs can be described with a *technical* specification
 - Spring constant = k
- Nonlinear springs are better described with *functional* specifications of the desired system-level behaviors
 - Minimum & maximum cell-face pressures




- Linear springs can be described with a *technical* specification
 - Spring constant = k
- Nonlinear springs are better described with *functional* specifications of the desired system-level behaviors
 - Minimum & maximum cell-face pressures












aspen aerogels[•]




aspen aerogels






Regroup Parts




Regroup Parts and Notice They Form a Two-Spring System




Visualizing C2C Barrier Response


aspen



Cell Response Is Described By Its Compressive Modulus




Cell Response Is Described By Its Compressive Modulus




Satisfying Equilibrium and Continuity


aspei




Cells + Cell Barriers Act as a Two-Spring Three-Spring System








BOL₁ - Post-Assembly Relaxed State (30% SOC)




aspen




EOL - Cells Swell and Breathe (100% SOC)

aspen




©Aspen Aerogels, Inc.

EOL - Effects of Fatigue, Creep, and Compression Set




aspen

The Module's Mechanical History Can Be Told with One Graph




aspen aerogels

Mechanical Outcomes Can Be Visualized with One Graph



Mechanical Outcomes Can Be Visualized with One Graph



- Parametric model delivers variation control over every spring in our "3-Spring" System
- Calculate new equilibrium condition for small variations in geometry and stiffnesses
 - Controlled by specified standard deviations (Cv) for each model component

©Aspen Aerogels, Inc.

 Iterate thousands of times to create a "cloud" of likely outcomes

aspen aerogels



Continue the Conversation Hall 10, Booth G81

Tyler Gurian

Senior Program Engineer, EV Thermal Barrier tgurian@aerogel.com